

①



Insert the square nut along the gap in the aluminum tube as the photo shows.

②



The first step is to complete the picture, do not fully tighten the bolts at this stage!

③



Install the end cap.

④



Connect the screw into the square nut on the roll top cover channel, make sure the gap is the same on both sides.

⑤



When you happy with the measurements tighten everything. The installation is complete, as shown in the picture!