

FUTURISTIC DRAWER SYSTEM FOR FORD RANGER 2012-2022







Before Installation













- Please read the instruction completely for easy installation, which will also help you to avoid scratches or other potential damages to your appealing car.
- The information shown here is for reference only and may differ from the product that you receive, however the goods are fitted in the same way.












Care and Cleaning


- Mild soap may be used also to clean the Product.
- Please periodically check and retighten all the hardware and clean the investment for a refresh look.

Parts list

NO.	QTY	PICTURE	NO.	QTY	PICTURE
①	1	 PANEL 1	②	1	 PANEL 2
③	1	 LEFT COVER	④	1	 RIGHT COVER
⑤	2	 STORAGE BASE	⑥	2	 SIDE SUPPORT BASE

⑦	1		⑧	1	
		FRONT SUPPORT BASE			REAR SUPPORT BASE
⑨	1		⑩	1	
		LARGE SIZE DRAWER			MIDDLE SIZE DRAWER
⑪	1		⑫	2	
		REAR FIX BRACKET			FRONT FIX BRACKET
⑬	1		⑭	1	
		BASE CONNECT BRACKET			MIDDLE PANEL SUPPORT BRACKET (WITH GUIDE RAIL)
⑮	1		⑯	1	
		LEFT PANEL SUPPORT BRACKET (WITH GUIDE RAIL)			RIGHT PANEL SUPPORT BRACKET (WITH GUIDE RAIL)
⑰	2		⑱	2	
		SUBPLATE			HEX FLANGE NUT BOLT M6_45
⑲	36		⑳	4	
		HEX FLANGE NUT BOLT M6_12			HEX FLANGE NUT M6


21	15		22	8	
		HEX FLANGE NUT BOLT M6_35			HEX FLANGE NUT BOLT M6_20
23	21		24	2	
		RUBBER PLUG			KEY
25	1		26	1	
		LEFT DECORATION PLATE			RIGHT DECORATION PLATE
27	1		28	1	
		LEFT FRONT CONNECT BRACKET			RIGHT FRONT CONNECT BRACKET
29	1		30	1	
		LEFT REAR CONNECT BRACKET			RIGHT REAR CONNECT BRACKET
31	2		32	1	
		FRONT CONNECT BRACKET			RUBBER STRIP

Installation Fig.


Step 1: Verify that all parts are present according to the manual.

Step 2: Screw ⑮ on ⑤ and ⑥ by ⑲, please notice that rail on ⑮ should head toward ⑤.


Please repeat this step for ⑯ on another side.




Step 3: Install ⑭ on ⑦ and ⑧ by ⑰, please notice that rail on ⑭ should head toward ⑧.



And then turn the above items, install ⑬ on ⑦ and ⑧ by ⑰.




Step4: Install ⑫*2 on ⑥ and ⑦ by ⑰.




Step 5: Stick (32) on the bed then put (6) on it.

Please repeat this step for another side.





Step 6: Disassemble the original hook of the bed(tailgate side), and then install by (29) the original bolt on the installation hole. Please repeat this step for another side.




Install (31) on (6) by (19), and then connect (27) with (31) by (19) and (20).

Please repeat this step for another side.




Disassemble the original hook of the bed(cabinet side), and then install ②⑦ by the original bolt on the installation hole.

Please repeat this step for another side.




Install ②⑨ on ⑤ by ①⑧, ①⑦ and ②⑩.


Please repeat the above step on another side.




Step 7: Install (11) on (8) and (5) by (19).




Step 8: Pull out about 300mm rail on (15)/(16), and then horizontally connect the rail on (9)/(10). Sounds of click mean the rail is connected and the drawer can be pushed inside.




Step 9: Install ① and ② on ⑭ and ⑥ by ⑳, and then screw ㉔ on ⑤.




Step 10: Install ㉓ in each hole of ① and ②, also put ③ on ① and ④ on ②.



*2: Press the cap downward to close





*1: Insert the cap into the installation hole of panel first



Step 11: Install (26) on (5) by (19).

Please repeat this step for (25) on another side.



Step 12: Installation finished



NOTE

Any damages and losses caused by improper installation and application, goes beyond our quality warranty.